

Installation guide

Packing bags

-

VW T5 / T6 / T6.1
Multivan Startline
Transporter
Beach (until 2010)

without lining

Watch the video:

<https://www.youtube.com/watch?v=sqwoeSTfE5M>



Take notice of the correct side: the VanEssa logo shows towards the boot (pic. 1).

Tip:
In order to avoid moisture behind the bags, take them out from time to time and let them dry during the day.



Plug the Z-angles on both sides of the window between lining and window glass (pic. 2).

Note:

If the Z-angles (due to tolerances in the distance between window and lining) can be inserted too loosely and do not hold on their own, stick the fleece tapes onto the angles.



Remove the left- and rightmost plug from the lower tin lining (pic. 3).



Push the angles of the aluminium bars into the aperture of the tin lining (pic. 4).



Remove the supplied foam chunks (pic. 5).

Tip:
You can keep them for compatibility with a VW T5/T6/T6.1 with lining.



Then thread the rear panel of the packing bags behind the Z-angles (pic. 6) and push them onto the aluminium bars and completely into the window slot (pic. 7).

If you have any further questions please contact us:
+49 (0) 8063 / 20 760 - 0 oder info@vanessa-mobilcamping.de

VanEssa mobilcamping | Lauser Strasse 27 | 83620 Grosshöhenrain | Deutschland
Tel. +49 (0) 8063/20 760-0 | info@vanessa-mobilcamping.de