

# Installation guide

## Packing bags

-

### PSA

*vehicle length*

*4,6 m / 4,9 m / 5,3 m*

Tip:  
*To avoid moisture behind the packing bags, take the bags out from time to time and let them dry during the day.*



Slide the darkening plate between the lining and the window (pic. 1 + 2).

Note:

*Vehicle belts can still be used as usual.*

*The only requirement for attaching the PSA packing bag is that the rear of the van is panelled.*



Thread the back of the packing bag behind the aluminum strip on the blackout panel (pic. 3 + 4).

Then push the bags into the window until the bag is firmly on the fairing.



The Velcro strap (red arrow, pic. 2) has two functions. It is used to remove the darkening plate and to prevent the packing bag, which also has Velcro at the bottom, from falling out.





Important objects such as the cell phone (pic. 6a), keys (pic. 6b) or sunglasses (pic. 6c) can be deposited at the additional applications.



At the length of 5.3 m, two packing bags can be attached next to each other (pic. 7).  
A pair, without additional blackout panel, can be ordered.



The vehicle length of 4.9 m with business equipment has a cover on each window (Fig. 8). It is possible that this is too close to the window so that the rear panel does not fit into the window. In this case, the cover would have to be removed (pic. 9).

Tip:

*First of all try to install the plate with cover.*

*The removal of the cover is not always necessary.*

If you have any further questions please contact us:  
+49 (0) 8063 / 20 760 - 0 oder [info@vanessa-mobilcamping.de](mailto:info@vanessa-mobilcamping.de)

VanEssa mobilcamping | Lauser Strasse 27 | 83620 Grosshöhenrain | Deutschland  
Tel. +49 (0) 8063/20 760-0 | [info@vanessa-mobilcamping.de](mailto:info@vanessa-mobilcamping.de)