Installation guide

VanEssa
mobilcamping

Arco-System -
Viano (Fun) / V-Klasse / Vito <u>with</u> rails / Pössl Vanstar /
Marco Polo Activity/Horizon

1. Installation Arco tunnel
- With the Horizon/Marco Polo Activity the right panel of the original bed extension needs to be removed (pic. 1).
- Place the tunnel(s) in the back of the car (pic. 2).
- Lay the slot nuts into the rails, push them unter the tunnel und screw the included countersunk screws through the tunnel bottom into the slot nuts (pic. 3).
- When using only one tunnel, hang the bed extension into the connection points on the side of the tunnel and place the stand upright (pic. 4).
- Connect both tunnels at the top with countersunk screws through the front and rear screw-in nut (not too tight).

2. Bed system assembly
- Lift the front edge of the sleeping board a little and pull it into the passenger compartment untill it engages in the connection points of the tunnel. The wooden pillar swings out automatically (pic. 5).
- Unfold the mattress(es) into the passenger compartment...and have a good sleep on our cosy VanEssa bed (pic. 6).

<u>Kitchen assembly:</u>
- When using the kitchen in the tunnel, lift it into the pullout with the drawers facing inwards (pic. 7).
- Secure the kitchen module with the included screw on the outer side (pic. 8).
- Place the coolbox on the console next to the kitchen module. Lead the cable under the console und plug the coolbox in (pic. 7).
- Trimm the cable length, clip it into the plastic plug und push the plug from the outside into the cutout on the side of the tunnel (pic. 9).

3. Storing
While driving with the sleeping board(s) in storage position, make sure that the bore holes on the bottom are engaged in the fittings of the tunnel/bed extension - especially when it is used without any seats (safety reasons). As an addtional fastening, you can fix board(s) and mattress(es) with tension belts (pic. 10).

If you have any further questions please contact us:
+49 (0) 8063 / 20 760 - 0 or info@vanessa-mobilcamping.de