

Installation guide

Floor plate T5/T6/T6.1 Transporter/Caravelle

1a. Installation single (front) floor plate (125x150 cm)

- Remove the screws of the front four tie-down rings and take the rings out (pic. 1).
- Floor plates with cutouts for the front seat bench: Place the ledge in the middle of the passenger room (pic. 2).
- Place the floor plate in the front passenger compartment with the apertures of the floor plates matching with the seat anchorings (pic. 2+3).

Note: The seat anchorings can be levelled with cover plates (pic. 6). We recommend the cover plates combined with a carpet. Without carpet, the cover plates can chatter.



1b. Installation complete floor plate (short wheelbase: 250x150 cm, long wheelbase: 290x150cm)

- Remove the screws of all tie-down rings and take the rings out (pic. 4).

Note: Depending on wheelbase, sliding doors and seat configuration, there can be more tie-down rings than the marked ones.

- Place both floor plates in the passenger compartment with the apertures of the floor plates matching with the seat anchorings. Make sure that the two plates click into each other at the cut (pic. 5).

Note: The seat anchorings can be levelled with cover plates (pic. 6). We recommend the cover plates combined with a carpet. Without carpet, the cover plates can chatter.



2. Fastening

- Position the floor plate(s) with the holes on the outside immediately over the threads of the tie-down rings and fix the plate(s) with the M10 countersunk screws (pic. 7+8).

Tip: You can align the floor plate(s) by sticking a screwdriver through each bore hole before the fastening (pic. 9).



If you have any further questions please contact us: +49 (0) 8063 / 20 760 - 0