

Installation guide


Surfer bed with kitchen

Mercedes Vito without rail system

VanEssa
mobilcamping

1. Bed system assembly

- Place the extension board on the aluminium angles on the rear side of the kitchen and fix it with the included countersunk screws (pic. 1). Support the extension board with an aluminium pillar on each side (pic. 2).
- Lift the front edge of the sleeping board a little and pull it into the passenger compartment until it engages in the connection points. The wooden pillar swings out automatically (pic. 3+4).
- Unfold the mattress into the passenger compartment...and have a good sleep on our cosy VanEssa bed (pic. 5).
- With the long wheelbase, the front seat row can remain in the car, if it is tiltable (pic. 6).



2. Storing

- While driving, the sleeping board lies on the rear kitchen. For safety reasons, make sure that the bore holes on the bottom of the folding board are engaged in the fittings of the rear board.
- As an additional fastening, we recommend the use of a tension belt - especially when the surfer bed is used without any seats (pic. 7).



If you have any further questions please contact us: +49 (0) 8063 / 20 760 - 0