

Installation guide

VanEssa
mobilcamping

Surferbed -

T5/T6/T6.1 Transporter/Caravelle (with 2nd row of seats)

1. Rear board installation

- Remove the screws of the rear tie-down rings and take the rings out (pic. 1).
- Position the rear board inside the vehicle (pic. 2).
- Fix the rear board on both sides by tightening a M10 screw into the threads of the tie-down rings (pic. 3).
- Mount the adjusting screws on both sides until they are fixed with the vehicle lining (pic. 4).

Note: For a VW Transporter with lining on both sides you have to replace the long adjusting screw by a short one which is included in delivery.



2. Bed system assembly

- Lift the front edge of the sleeping board a little and pull it into the passenger compartment until it engages in the connection points and put it on the seats (pic. 5).

Note: If only the 2-seater bench is installed without the single seat, you need the support foot (pic. 6).

If the complete row of seats is removed from time to time, use the aluminium pillar (pic. 7).

- Unfold the mattress(es) into the passenger compartment...and have a good sleep on our cosy VanEssa bed.



3. Storing

While driving with the sleeping board in storage position, make sure that the bore holes on the bottom are engaged in the fittings of the extension board - especially when it is used without any seats (safety reasons). As an additional fastening, you can fix board(s) and mattress(es) with tension belts (pic. 8).

If you have any further questions please contact us: +49 (0) 8063 / 20 760 - 0

VanEssa mobilcamping | Lauser Strasse 27 | 83620 Grosshöhenrain | Germany
Tel. +49 (0) 8063/20 760-0 | info@vanessa-mobilcamping.de