

Installation guide

V1 kitchen

Tourneo Custom/Transit Custom - short wheelbase

VanEssa
mobilcamping

1. Installation

- Remove the lower screws of the outer seat rails (pic. 1+2).
- Place the mounting plate in the car and fasten it with the included M12 countersunk screws (pic. 3+4).
- The drawers can be taken out in order to reduce the kitchen's weight.

Note: Push the orange clips at the bottom of the drawers simultaneously and take it out (pic. 6).

- Place the kitchen in the back of the vehicle (pic. 5). For a more convenient installation we recommend the use of our mounting trolley.



2. Fastening

- Fix the kitchen left and right on front and back to the mounting plate by screwing the star knob screws through the kitchen bottom into the screw-in nuts of the plate (pic. 7-9).
- Push the drawers back into the kitchen until they engage.



3. Electrics & Water tank

- Plug the cable from the kitchen into a 12 Volt socket. Draw the included spring with the screw in one of the threads at the back of the coolbox. The spring holds the cable up and thereby avoids the cable to be clamped (pic. 10+11).
- The opening lid must be adjacent to the fridge/freezer. The water hose has to be placed like a loop (pic. 12).
- Empty water tank and hose completely after touring to avoid frost damage, calcification, bacteria etc..



If you have any further questions please do not hesitate to contact us:
+49 (0) 8063 / 20 760 - 0 or info@vanessa-mobilcamping.de