

# Installation guide

## V1 kitchen(T) -

### Vivaro B/Trafic III/Talento/NV300 from 2016

VanEssa  
mobilcamping

#### 1. Installation

- Thread the lashing strap through the red loop and place it under the seat bench (pic. 1).
- In case you also use our bed system, carefully remove the marked part of the linings (pic. 2).
- The drawers can be taken out in order to reduce the kitchen's weight.

*Note: Push the orange clips at the bottom of the drawers simultaneously and take it out (pic. 3).*

- Place the kitchen in the back of the vehicle (pic. 4).

*Tip: For a more convenient installation we recommend the use of our mounting trolley.*



#### 2. Fastening

- Push the screws through the holes in the kitchen's sides into the holding fixture of the lower hat rack (pic. 5).
- Screw the four screws to the outside with an Allen key (pic. 6-9).
- Push the drawers back into the kitchen until they engage.



#### 3. Electrics & Water tank

- Plug the cable from the kitchen into a 12 Volt socket. Draw the included spring with the screw in one of the threads at the back of the coolbox. The spring holds the cable up and thereby avoids the cable to be clamped (pic. 10+11).
- The opening lid must be adjacent to the fridge/freezer. The water hose has to be placed like a loop (pic. 12).
- Empty water tank and hose completely after touring to avoid frost damage, calcification, bacteria etc..



If you have any further questions please do not hesitate to contact us:  
+49 (0) 8063 / 20 760 - 0 or [info@vanessa-mobilcamping.de](mailto:info@vanessa-mobilcamping.de)

VanEssa mobilcamping | Lauser Strasse 27 | 83620 Grosshöhenrain | Germany  
Tel. +49 (0) 8063/20 760-0 | [info@vanessa-mobilcamping.de](mailto:info@vanessa-mobilcamping.de)