

Installation guide

V2/V3 kitchen - Fiat Doblo II/ Opel Combo D (2011-2018)

VanEssa
mobilcamping

1. Installation (The V3 kitchen is needed, when there is a lower hat rack; pic. 1+2)

- The drawers can be taken out in order to reduce the kitchen's weight.

Note: Push the orange clips at the bottom of the drawers simultaneously and take it out (pic. 5+6).

- Remove the screws of the rear tie-down rings and take the rings out (pic. 3).

- Place the kitchen in the back of the vehicle (pic. 5). For a more convenient installation we recommend the use of our mounting trolley (pic. 4).



2. Fastening

- Fix the kitchen with the countersunk screws left and right through the bottom into the threads of the tie-down rings. Use the lowermost of the three adjacent holes (V2) respectively the little staggered one (V3). The other holes in the kitchen's bottom are there for compatibility with other vehicles (pic. 7+8).

Note: To find the threads of the tie-down rings easier, plug a screwdriver into the hole, lift the kitchen a little and arrange the kitchen above the thread of the threads of the tie-down rings.

- Push the drawers back into the kitchen until they engage (pic. 9).



3. Electrics & Water tank

- Plug the cable from the kitchen into a 12 Volt socket. Draw the included spring with the screw in one of the threads at the back of the coolbox. The spring holds the cable up and thereby avoids the cable to be clamped (pic. 10+11).

- The opening lid must be adjacent to the fridge/freezer. The water hose has to be placed like a loop (pic. 12).

- Empty water tank and hose completely after touring to avoid frost damage, calcification, bacteria etc..



If you have any further questions please do not hesitate to contact us:
+49 (0) 8063 / 20 760 - 0 or info@vanessa-mobilcamping.de

VanEssa mobilcamping | Lauser Strasse 27 | 83620 Grosshöhenrain | Germany
Tel. +49 (0) 8063/20 760-0 | info@vanessa-mobilcamping.de