

# Installation guide

## V2 kitchen Ford Tourneo Grand Connect (=long wheelbase)

VanEssa  
mobilcamping

### 1. Installation

- With the 7-seat version, the last seat row needs to be removed.
  - Place the mounting plate in the back of the car with the slots over the inner tie-down rings (pic. 1).
  - Thread the hook screws into the tie-down rings und fasten the star knob screws (pic. 2).
  - The drawers can be taken out in order to reduce the kitchen's weight.
- Note: Push the orange clips at the bottom of the drawers simultaneously and take it out (pic. 4).*
- Push the kitchen onto the mounting plate until the bore holes at the back of the match with the screw-in nuts of the mounting plate (pic. 3).

*Tip: For a more convenient installation we recommend the use of our mounting trolley.*



### 2. Fastening

- Fix the kitchen to the mounting plate by fastening the star knob screws left and right on the back through the kitchen's bottom into the screw-in nuts (pic. 5).
- Push the drawers back into the kitchen until they engage (pic. 6).



### 3. Electrics & Water tank

- Plug the cable from the kitchen into a 12 Volt socket. Draw the included spring with the screw in one of the threads at the back of the coolbox. The spring holds the cable up and thereby avoids the cable to be clamped (pic. 7+8).
- The opening lid must be adjacent to the fridge/freezer. The water hose has to be placed like a loop (pic. 9).
- Empty water tank and hose completely after touring to avoid frost damage, calcification, bacteria etc..



If you have any further questions please do not hesitate to contact us:  
+49 (0) 8063 / 20 760 - 0 or [info@vanessa-mobilcamping.de](mailto:info@vanessa-mobilcamping.de)