

Installation guide

VanEssa
mobilcamping

Vaude Drive Van tent (youtube.com/watch?v=nl_kHGRtgPI)

- Unfurl the tarpaulin properly on the floor, with the Vaude logos visible (pic. 1).
- Plug the poles of the main beam (orange ends) together and hook the ends into the eyes on the red straps of the tarpaulin (pic. 2+3).
- Click the lateral clips into the main beam (pic. 3+4).



- Plug the two lateral beams together and into the joint of the main beam afterwards (pic. 5).
- Hook the ends into the eyes on the gray straps of the tarpaulin (pic. 6). Do not click the clips of the lateral beams into the beams meanwhile (pic. 7).
- Plug the two short beams together and into the other side of the joint.
- Lift the tent a little and lever the short beams downwards for the tent to unfold. Plug the stoppers on the tarpaulin into the ends of the short beams (pic. 8+9).
- Click the remaining clips into the beams and the tent is ready (pic. 10).



If you have any further questions please contact us: +49 (0) 8063 / 20 760 - 0