

Installation guide

Arco system - Storage on the tunnel

Assembly

- Make sure that the holes on the underside of one sleep board engage with the fittings on the tunnel.
- Then place the double bed extension, the other sleeping board and both mattresses on the tunnel (pic. 1).
- Hang the carabiner on the aluminum bar (pic. 2).

Variant 1:

- Pull the lashing strap through the carabiner on the aluminum bar (pic. 3).
- Then fasten the lashing strap to the grab handle on the passenger side (pic. 4).

Variant 2:

- If there is no grab, fix the ring loop on the tunnel for the 2nd carabiner and hook the carabiner on the loop (pic. 5).
- First pull the lashing strap through the carabiner on the aluminum bar (pic. 6).
- Place the lashing strap over the mattress and thread it through the 2nd carabiner. Put the lashing strap back under the mattresses to fix (pic. 6+7).

Note: Towards the front, the system is best fixed when a (single) seat is placed in front of it.



If you have any further questions please contact us:
+49 (0) 8063 / 20 760 - 0 oder info@vanessa-mobilcamping.de